

## Frequenzübersicht

Deutschland 27 MHz/Band		
Kanal	Frequenz	Alternativ
4	26,995	Band 1
5	27,005	
6	27,015	
7	27,025	
8	27,035	
9	27,045	Band 2
10	27,055	
11	27,065	
12	27,075	
13	27,085	Band 3
14	27,095	
15	27,105	
16	27,115	
17	27,125	
18	27,135	
19	27,145	Band 4
24	27,195	Band 5
30	27,255	Band 6

Deutschland 40 MHz/Band	
Kanal	Frequenz
50	40,665
51	40,675
52	40,685
53	40,695
54	40,715
55	40,725
56	40,735
57	40,765
58	40,775
59	40,785
81	40,815
82	40,825
83	40,835
84	40,865
85	40,875
86	40,885
87	40,915
88	40,925
89	40,935
90	40,965
91	40,975
92	40,985

Belgien 40 MHz/Band	
Kanal	Frequenz
1	40,665
2	40,675
3	40,685
4	40,695
5	40,715
6	40,725
7	40,735
8	40,765
9	40,775
10	40,785
11	40,815
12	40,825
13	40,835
14	40,865
15	40,875
16	40,885
17	40,915
18	40,925
19	40,935
20	40,965

Japan 40 MHz/Band	
Kanal	Frequenz
61	40,610
63	40,630
65	40,650
67	40,670
69	40,690
71	40,710
73	40,730
75	40,750

Frankreich 41 MHz/Band	
Kanal	Frequenz
400	41,000
401	41,010
402	41,020
403	41,030
404	41,040
405	41,050
406	41,060
407	41,070
408	41,080
409	41,090
410	41,100
411	41,110
412	41,120
413	41,130
414	41,140
415	41,150
416	41,160
417	41,170
418	41,180
419	41,190
420	41,200